

# INSTALLATION OF SATURN B TELEX SOFTWARE

Please find 3 diskettes enclosed.

- 2 Diskettes with Saturn B Telex Program
- 1 Formatted Data Diskette

The two Saturn B Program diskettes are identical. One of the diskettes should be saved for emergency back-up only.

The Data Diskette can be used directly for storing of send/receive messages, or as back-up diskette for same.

1. Store one of the diskettes named "Saturn B Telex" installation diskette in a safe place.
2. Insert the second "Saturn B Telex" diskette into disk drive (e.g. drive "A").
3. Switch ON the PC and wait until A:\>\_ is displayed on the screen.
4. Type "INSTALL" and press the ENTER key. An introduction text will be displayed. Read text and press any key.
5. Follow the text and select the appropriate choices for the PC, until the display indicates completion of the installation (takes 3-4 minutes).
6. Remove the diskette and restart the PC by pressing keys CTRL + ALT + DEL simultaneously, and then release them; or turn the PC power OFF and ON again.
7. If any errors during installation, start from step 2 again.

*Note !*

*General requirements of PC for operation with Saturn B Telex are as follows:*

- *I/O HW shall be 100% IBM compatible*
- *3.5" 1.44MB floppy disk drive*
- *Serial port for communication with Saturn B Centronics interface for printer.*
- *Monochrome screen or better*
- *English keyboard*
- *PC shall be equipped with speaker for alarms*
- *MS-DOS PC 3.1 or later version*
- *Minimum 580 kB available in the 640 kB memory*
- *386 processor or better*
- *Minimum 4 MB RAM*

---

# NERA